

## SHOWER / TUB ENCLOSURE

Let Southern Lumber shower you with possibilities.

### LIST OF NEEDED STEPS:

1. Carefully take measurements of existing opening.
2. Next note direction that door(s) needs to swing or roll.
3. Look at displays.
4. Determine design.
5. Explore glass designs and select.
6. Decide on your color choice for frame components.
7. Place order (stock designs 1-week, custom 3-4 weeks)
8. Once ready for installation, carefully start by removing ALL of the old door(s) and frame, Next clean off any remaining caulking or seal.
9. Next carefully measure for bottom track and cut to size.
10. Apply serpentine bead of caulking to bottom track location and install.
11. Next start installation of side tracks, You will need to use a level and position tracks in "Plumb" manner, Mark each hole location and drill for insertion of masonry anchor.
12. Install each side track.
13. You will now need to measure for top track, then cut and install.
14. You're now ready to hang doors and adjust rollers for correct fit.

### CHECKLIST OF NEEDED SUPPLIES:

- Shower / Tub Enclosure
- Caulking
- Wall Anchors

### RECOMMENDED TOOLS:

- ✓ Hammer
- ✓ Hack Saw (with 32 TPI Blade)
- ✓ Level
- ✓ Screwdriver
- ✓ Drill
- ✓ Masonry drill bit
- ✓ Safety Goggles

PROJECT DIFFICULTY:

NOVICE

HOME HOBBYIST

INTERMEDIATE

ADVANCED