

THRESHOLD/TRANSITION STRIP REPLACEMENT

Let Southern Lumber help you create a custom threshold to complete the job.

LIST OF NEEDED STEPS:

1. Determine the size and shape of transition needed.
2. Select the specie of wood to be used.
3. Discuss milling to be performed and fees to be charged.
4. Have transition strip made.
5. Select fasteners (Nails or Screws).
6. Select proper sandpaper to be used.
7. Determine Stain and Finish to be used.
8. Select color matched Putty/Filler.

CHECKLIST OF NEEDED SUPPLIES:

- | | |
|---|---|
| <input type="checkbox"/> Wood | <input type="checkbox"/> Stain cloth Applicator |
| <input type="checkbox"/> Putty/Filler | <input type="checkbox"/> Paint Brush |
| <input type="checkbox"/> Primer & Paint | <input type="checkbox"/> Sandpaper |
| <input type="checkbox"/> Stain & Finish | <input type="checkbox"/> Tack Cloth |
| <input type="checkbox"/> Thinner | <input type="checkbox"/> Drop Cloth |

RECOMMENDED TOOLS:

- | | |
|--|--|
| <input checked="" type="checkbox"/> Hammer | <input checked="" type="checkbox"/> Screwdriver |
| <input checked="" type="checkbox"/> Hand Saw | <input checked="" type="checkbox"/> Sander |
| <input checked="" type="checkbox"/> Drill | <input checked="" type="checkbox"/> Can Opener |
| <input checked="" type="checkbox"/> Putty Knife | <input checked="" type="checkbox"/> Safety Goggles |
| <input checked="" type="checkbox"/> Tape Measure | |

PROJECT DIFFICULTY:

NOVICE

HOME HOBBYIST

INTERMEDIATE

ADVANCED