

VANITY REPLACEMENT

The easiest way to spruce up your Bathroom.

LIST OF NEEDED STEPS:

1. Carefully measure affected wall.
2. Measure the location of Water supply lines and Drain fittings.
3. Make your vanity selection. Be sure to take into consideration what type of top will be used. Southern Lumber stocks over 35 different styles and sizes to choose from or select from a variety of Special order designs all available in 3 weeks.
4. Once you're ready to start, first turn off water from water supply valves.
5. Remove old faucets, sinks, and cabinets.
6. Clean area and repair any damage to walls and floors that won't be accessible after new vanity is in place.
7. Place new cabinet, check for even gap along wall. Scribe moulding may be needed for wide or irregular gaps.
8. Secure cabinet to wall with screws through backboard into wall studs.
9. Install new faucet and connect supply lines.
10. Attach new vanity top with adhesive caulking. Check for leaks.

CHECKLIST OF NEEDED SUPPLIES:

- | | |
|---|---|
| <input type="checkbox"/> Vanity Cabinet | <input type="checkbox"/> Drain Fittings |
| <input type="checkbox"/> Top | <input type="checkbox"/> Caulking |
| <input type="checkbox"/> Faucet | <input type="checkbox"/> Plumbers Putty |

RECOMMENDED TOOLS:

- | | |
|---|---|
| <input checked="" type="checkbox"/> Hammer | <input checked="" type="checkbox"/> Stud Finder |
| <input checked="" type="checkbox"/> Screwdriver | <input checked="" type="checkbox"/> Hand Saw |
| <input checked="" type="checkbox"/> Adjustable wrench | <input checked="" type="checkbox"/> Drill |
| | <input checked="" type="checkbox"/> Utility Knife |

PROJECT DIFFICULTY:

NOVICE

HOME HOBBYIST

INTERMEDIATE

ADVANCED