

WOOD ARBOR

Let Southern Lumber help you create your backyard dream with a wood arbor cut to order.

LIST OF NEEDED STEPS:

1. Create design or drawing.
2. Select type of lumber to be used.
3. Determine the design to be used on the ends of Rafters/Beams.
4. Select the type of fasteners/connectors to be used.
5. Select the Stain and or Finish.
6. Develop a material cut list from drawing.
7. Perform necessary milling (or have Southern Lumber cut it for you).
8. Separate material in order of use i.e. Post, Beams, Rafters.
9. Start by staking area using Mason line and wood stakes, measure to make sure that layout lines are square.
10. Mark post locations and check to insure that spacing will work.
11. Dig post holes, and place post in hole.
12. Plumb post and secure with stakes at right angles.
13. Pour concrete to anchor post.
14. If you are mounting the post onto an existing concrete patio you will use an adjustable post base with stand-off plate.
15. Anchor post base by drilling and inserting concrete stud anchors.
16. Once posts have been properly anchored proceed with Arbor assembly.

CHECKLIST OF NEEDED SUPPLIES:

- | | |
|-----------------------------------------------------------|----------------------------------------|
| <input type="checkbox"/> Lumber | <input type="checkbox"/> Paint Brush |
| <input type="checkbox"/> Fasteners | <input type="checkbox"/> Paint Thinner |
| <input type="checkbox"/> Wood Connectors | <input type="checkbox"/> Bucket |
| <input type="checkbox"/> Primer & Paint or Stain & Finish | |

RECOMMENDED TOOLS:

- | | |
|--------------------------------------------|---------------------------------------------------|
| <input checked="" type="checkbox"/> Hammer | <input checked="" type="checkbox"/> Screwdriver |
| <input checked="" type="checkbox"/> Drill | <input checked="" type="checkbox"/> Wrench/Socket |
| <input checked="" type="checkbox"/> Level | |

PROJECT DIFFICULTY:

NOVICE

HOME HOBBYIST

INTERMEDIATE

ADVANCED